



Liquid Oxygen Safety

Transporting Liquid Oxygen

A) Truck Body

When transporting liquid oxygen, the cargo compartment needs to have a minimum of two vents in the forward portion of the cargo area and two in the rear portion. Vents need to be as close to the floor line as possible. At a minimum, the total natural ventilation must provide 1 square foot per 300 square feet of compartment ceiling area.

B) Bulkhead

The driver's compartment must be separated from the transfilling and cargo areas to prevent a build-up of oxygen enriched atmosphere from entering the driver's area. Fixed windows are permitted when transporting liquid oxygen.

C) Non-Acceptable Materials For the Cargo Area

No combustible materials such as paneling, plywood, or carpet should be used in the cargo area when transporting liquid oxygen. Diamond plating is advised.

D) Outside Ventilation

Any vessels permanently installed in the vehicle must have all safety and vessel vent discharge lines piped outside the vehicle. These vents must be designed so that they are not likely to discharge onto oil or asphalt surfaces or other combustible material or into the vehicles exhaust system when transporting liquid oxygen. If they discharge upward, they should have weather protection. Vessels not permanently installed in the vehicle should be suitably restrained during transit to prevent them from moving or tipping over.

E) Personnel

Vessels should be filled by trained personnel only.

F) Filling in Vehicle

When filling inside the cargo area, all doors should be opened and vent gas should be directed outside. In the interest of liquid oxygen safety, vessels should not be filled when the vehicle is in motion or when engine is running. When vessels are filled outside of vehicle, precautions should be taken to avoid any liquid or gas coming into contact with asphalt or other combustible material.

G) Before Starting Engine

Liquid oxygen safety regulations recommend draining all transfer lines and allowing oxygen vapors to disperse before starting engine of vehicle.

H) Signs

So others comply with liquid oxygen safety, clearly post signs inside and outside the vehicle prohibiting smoking and open flames.

continued on page 2

Transporting Liquid Oxygen *continued from page 1*

I) Placards

Liquid oxygen safety precautions in the United States state that vehicles and containers must be marked, placarded and labeled in accordance with TITLE 49 of the Code of Federal Regulations and all other federal, state and municipal regulations. Liquid oxygen safety precautions in Canada state that this must comply with the regulations of Transport Canada.

Call for information about parts, accessories, and repair services.

1.800.426.2186



CRYOFAB

sales@cryofab.com | 1-800-426-2186